

SER005S1P-15-10-30

SER = Single Phase Electric
Hoist, Hook Mount, Friction
Clutch

Capacity

003 = 1/4t
005 = 1/2t
010 = 1t
020 = 2t
030 = 3t

Speed

C = common
L = low
S = standard

Voltage

1 = 115v
2 = 220v

Suspender

omit = hook

P = perpendicular
lug for plain trolley

G = parallel lug for
geared trolley

Load Chain

= custom
0 = none
10 = std

Pendant Cord

= custom
0 = none

*Standard is 2 ft. less
than load chain drop*

Power Cord

= custom
0 = none

Standard is 15 ft.

ER2 = Three Phase Electric Hoist, Hook Mount, Friction Clutch

ER2M = Three Phase Electric hoist and trolley, lug mount, friction clutch

ER2001H4-12-12-15

Capacity

001 = 1/8t
003 = 1/4t
005 = 1/2t
010 = 1t
020 = 2t
030 = 3t

Speed

C = common
L = low
S = standard

Voltage

2 = 220v
4 = 440v
5 = 575v

Suspender

omit = hook

P = perpendicular lug for plain trolley

G = parallel lug for geared trolley

M = T-suspender for motorized trolley

Load Chain

= custom
0 = none
10 = std

Pendant Cord

= custom
0 = none
NPB = no push button

Standard is 2 ft. less than load chain drop

Power Cord

= custom
0 = none

Standard is 15 ft.

BS-ER2SP005S-100W30

BS-ER2 or
BS-CB = Bucket Steel for
Hoist only

BS-ER2SP/G/M Or
BS-CBSP/SG = Bucket
Steel for Hoist and Trolley
combo

Capacity

001 = 1/8t
003 = 1/4t
005 = 1/2t
010 = 1t
020 = 2t
030 = 3t
~

Speed

C = common
L = low
S = standard

Load Chain

= Length of Lift

Extension Shaft

W30 up to 12" Flange
WF for Flanges larger than 12"

TNER = Three Phase Electric Hoist,
Black, low visibility Inverted
Plug and play voltage changer
Pull rotor brake

TNER010L4-60-3DP

Capacity
005 = 1/2t
010 = 1t
020 = 2t

Speed
L = low
S = standard

Voltage
2 = 220V
4 = 440V

Load Chain
= custom
0 = none

Pendant & Power Cord
= custom
0 = none

Cord Options
DP = double pig tail, no push button
SP = single pig tail 7C wire, no push button
SOC = single pig tail with Socapex Connector